


MEGAMAN® PIR Sensor Module

LA11155+LA11197



Instruction Manual | Bedienungsanleitung | Manual de instrucciones | Manuale d'istruzioni | Manuel d'instructions | Handleiding | Návod k použití



10sec/5min/10min/15min/20min

15lux/30lux/50lux/disable

STARTUP

H (m)	WØ (m)*
2 (min.)	5
3	7
4	11
5	13
6	13
7	14
8	14

*±20% tolerance subject to environmental conditions

220-240V~

50/60 Hz

Ta
-20°C ~ +50°C

IP66
Assembled with HAGON

IK08

